


Portable Sensor Light

SET - UP AND OPERATION

A battery operated, portable sensor light ideal for use in and around the home, or when travelling. Pocket sized light functions as both movement activated or manual light.

- ⚠ Please read these instructions before use
- ⚠ This light is for indoor use only
- ⚠ Do not attempt to disassemble unit
- no user-serviceable parts inside




To insert batteries

- ⚠ It is recommended that you do not insert batteries if intending to permanently operate the light on mains power, as batteries will deteriorate.

Place the light face down on a soft stable surface. Remove the battery cover by pressing down on the tab to slide off.

Insert 4 x AA batteries (Alkaline) as shown and replace the cover.



To connect to mains power

Insert the AC adapter plug into the socket at the side of the light. Before connecting to mains power, ensure the power cord is fully unravelled. Plug into mains power and switch on at the power point.

- ⚠ The AC adapter will not charge the batteries.

To operate

ON position

Slide the switch located on the side of the light to ON. The light will turn on and remain on until switched to OFF.

AUTO position

- ⚠ In AUTO, the light will not turn on in daylight conditions

Slide the switch located on the side of the light to AUTO. The light should illuminate for 40 seconds whilst the sensor stabilises.

If there is no motion within the detection area the light will turn off in approximately 20 seconds.

The light will automatically illuminate if motion is detected, and remain on as long as motion is detected.

- ⚠ Do not stare directly at the light : bulbs are extremely bright and may cause eye injury

Bulbs

LED bulbs are non-replaceable. Do not disassemble unit.

Cleaning

Unplug the AC adapter from the light and the wall before cleaning.

Place the light on a flat, clean surface and gently wipe with a dry or slightly damp cloth. Do not use liquid cleansers or detergents.

Warranty

Novis Healthcare Pty Ltd warrants this product for a period of 12 months. Please refer to our Warranty Statement for full details.

Specifications

CODE	PL-PIR
COLOUR	White
VOLTAGE	6V DC or 4 x AA batteries
BULB	Non-replaceable 9 SMD LED light
LIFETIME	100,000 hours (approx.)
WARRANTY	1 year
MADE IN CHINA	